

GENERAL THEATRE QUICK TIPS – SuperCow Trolley

Below you will find some general quick tips to help you navigate the Button Controller.

Turn the system on:

Touch the ON Button to activate.



1. Turn the system on: Touch the ON Display option to activate.

2. Volume: Use the buttons to raise and lower the volume.

3. PC: Use the PC button to display content from the Micro PC attached. Please ensure that the PC is plugged into power socket and is switched on.

4. Laptop: Use the Laptop button to display HDMI source. Check that HDMI cable is connected.

Audio Input: A 3.5mm audio jack input is available for devices such as iPhone, iPad etc.

HDMI Input: plug in a HDMI cable to your laptop and select the laptop option from the button controller.

Switch the system off when you are finished using the Supercow Trolley.

Note: The button controller and PC are mounted on the back of the trolley.

A speaker and inbuilt microphone are mounted on the front of the trolley.

