


Below you will find some quick tips to help you connect your BYOD (bring your own device) to the projector over Wireless Presenter


**Turn the system on:**

Touch the panel to activate. Panel will then show as below.



**Projector**

1. **Wireless Presenter:** Select Wireless Presenter
2. **Select display:** Send to projectors (required in some rooms)
3. **Audio:** Ensure audio is set to an appropriate level and not muted (required in some rooms)
4. **Download Plugins:** Enter the link displayed along the top of the projector/monitor into a web browser on your device (eg. 10.25.1.51). You will then be prompted to download plugins specific to the device you are using



**Laptop**

5. **Prompt:** Laptop prompt after entering the IP address
6. **Log on:** You will then need to log into AirMedia. The *Code* is projected on the projector/monitor on the top right of the landing page.



**Android/IOS Device**

7. **Download App:** Download app from Device App Store
8. **Select Receiver Host:** Select *Tap to Enter Receiver Host Name or IP*. Enter the IP address which is displayed on the projector (eg. 10.25.1.51) The *Login* is the code projected on the projector/monitor on the top right of the landing page.

